

concept MM/MC Package

Operation instruction for tonearm counter weight (concept MM MC /wood with gimbal-mounted bearing)

With the concept MM / MC (Wood) you received a Plug & Play turntable. However for security reason you will find the counter weight for the tonearm separately packed.


1. To install the counter weight, please push it with pressure, but also carefully, on the shaft up to the black marking ring (see picture 1, 2 and 3). Please hold tight the tonearm tube when you push the counter weight onto the shaft!



Pic. 1: Delivery condition as supplied to customer (without installed counter weight)



Pic. 2: Installing the counter weight



Pic. 3: Final position of the counter weight

2. Please adjust tracking force with the delivered Smart Stylus gauge

For **Clearaudio** cartridge Moving Magnet (MM) is the tracking force= 2.4g

For **Clearaudio** cartridge Moving Coil (MC) is the tracking force = 2.2g

Operation instruction Smart Stylus gauge:

To adjust the tracking force of the cartridge, please follow the instructions provided:



concept MM/MC Package

Bedienungshinweise für Tonarm Gegengewicht (concept MM / MC (wood) mit kardanischer Lagerung)

Mit dem concept MM / MC (wood) haben Sie einen Plug & Play Plattenspieler erworben. Aus Sicherheitsgründen wurde jedoch das Gegengewicht für den Tonarm separat verpackt.

1. Um das Gegengewicht zu montieren, drücken Sie dieses bitte mit etwas Druck, aber dennoch vorsichtig auf das Tonarmrohr bis zu dem schwarzen Markierungsring (siehe Bild 1, 2 und 3). Bitte halten Sie den Tonarm fest, wenn Sie das Gegengewicht montieren!



Abb. 1: Lieferungszustand (ohne Gegengewicht)



Abb. 2: Montieren des Gegengewichts




Abb. 3: Endgültige Position des Gegengewichts

2. Bitte passen Sie die Auflagekraft mithilfe der mitgelieferten Smart Stylus gauge an

Für clearaudio Moving Magnet Tonabnehmer (MM) ist die Auflagekraft= 2,4 g

Für clearaudio Moving Coil Tonabnehmer (MC) ist die Auflagekraft = 2,2 g

Bedienhinweise Smart Stylus gauge:

Bitte befolgen Sie folgende Hinweise, um die Auflagekraft Ihres Tonabnehmers einzustellen.

